

SPYDER GROUP

Where Design Meet Aspiration


Product Installation Manual SKU : KC-112



Tools Required (Not Included)



Hammer



2-in-1
Screw Driver

00:45


Approx 45 mins



Recommended
2 Person

20KG

Recommended Max
Weight




Exploded View

Packing List	Qty	Minifix Bolt	16	Handle Screw	6
Wooden Boards (assorted sizes)	15	Dowel	16	Bullet Pins	12
Board Screw (3.5 X 16 mm) Black	6	Door hinge	2	Wall plug and screw	x6 Each
Minifix Housing	16	Handle	3		



Useful Hints Before You Start:

1. Read all instructions carefully before beginning the assembly.
2. Follow each step in the correct order to avoid difficulties during the process.
3. Assemble the furniture on a clean, flat, and soft surface to prevent any damage to the parts.
4. Identify all boards and hardware items (such as nuts, bolts, hinges, dowels, etc.) before starting.



Step 1 : Insert **Dowels** and **Minifixes bolt** into **Board 1** as shown in **Figure 1**.



Step 2 : Keep **Board 2, 3 & 4** on **Board 1** as Shown in **Figure 2**. Fasten the **Minifix Housing** on **Board 2, 3 & 4**.



Step 3 : Fix Minifixs & Dowels on **Board 2 & 4** as shown in **Figure 3**. Tilt **Board 2 & 4** a little to fix **Board 5** between **Board 2 & 4** respectively. Fasten the Minifix Housings as shown in figure below.



Step 4 : Slid the **Board 6 & 7** in the grooves of **Board 2 & 4**.

Place **Board 8, 9 & 10** on Bullet Pins as shown in figure.




Figure 4

Step 5 : Insert **Dowels** and **Minifixs Bolt** into **Board 11** as shown in **Figure 5**.

Insert **Minifix Housings** in **Board 2, 3 & 4** and join **Boards 11** as shown in figure, fasten minifixs housing in **Boards 2, 3 & 4** with the help of screw driver as shown in figure below.




Figure 5

Step 6 : Join **Board 2 & 12** as shown in Figure below. Fix the **Door Hinges** with the help of **(2 x 4 screw)** on **Board 2 & 12** fasten it with Screw Driver as shown. Similarly affix the other doors (**Board 13 on Board 3** and **Board 14 on Board 4**).




Figure 6

Step 7 : Fasten Handle with screw on **Board 12, 13 & 14** (Doors).




Figure 7



Step 8 : Affix Board 15 on wall. Hang the Cabinet assembly onto the Board 15 as shown in Figure 8.




Figure 8

**“All we need is customers valueable feedback.
That’s how we’ll improve.”**

Need help in Assembling?

- Having trouble installing this product?
- Need a paid professional carpenter?
- You can now avail our paid installation service.
(Available at selected locations only)

Contact our support team



1800-572-3961



support@spydergreen.com

Replacement Policy

- Returns and refunds are eligible within 15 days of delivery.
- If the refund will be made if the delivered product is undamaged, functional, and unchanged.
- You must provide proof of the item's defect, like photographs or videos that showcase or highlight the fault or defect in the product.
- The product must be in its original packaging and unused.
- All accessories, manuals, and other accompanying items must not be missing.

Warranty Terms and Conditions

All Spyder Green's products are covered under a 1-year warranty against manufacturing defects. The warranty is applicable only upon presentation of the original purchase invoice at the time of service.

Warranty Covers :

- Manufacturing defects in functional parts
- Termite or fungus-related issues
- Color fading due to manufacturing fault
- Complete product failure due to production issues

Warranty Does Not Cover :

- Damages due to misuse, mishandling, or negligence
- Unauthorized use or tampering
- Improper installation not done by authorized personnel
- Continuous exposure to water or moisture
- Damage caused by natural calamities
- Normal wear and tear from regular use
- Damage due to unauthorized modifications or alterations.

This warranty is non-transferable, valid only within India, and extended exclusively to the original end-user customer.

How to Request a Replacement for the Product?

Spyder Green provides an easy and hassle-free replacement policy. Follow the below mentioned steps:-

- You can directly put the replacement request in the order section.
- If you have requested a refund after a long period, you can contact us via phone, email, or WhatsApp.
- We also provide repair assistance by scheduling a technician visit to your location.
- Based on the technician's evaluation, we provide a resolution. However, this service is chargeable.
- Our technicians replace the defective parts. However, if replacing the parts of the furniture items does not resolve the issue; we approve the full replacement of the product.